

CARE INSTRUCTIONS

Caring for your Tri Climb is not only essential for improving safety, but will also add years to its life for your children to play on and enjoy it as they grow.

WARNING: if the checks and maintenance of the Tri Climb are not carried out the activity toy could overturn or otherwise become a hazard.

*All bolts and fixings should be checked regularly and tightened if necessary.

*It is important to check your Tri Climb for wear and damage regularly. If you are unsure as to the integrity of any component, replace it immediately.

*We recommend that you regularly check your climbing frame for splits, broken or cracked wood, missing, loose or sharp edged hardware – replace, tighten and/or sand smooth as required prior to playing.

*The wooden components are manufactured from FSC birch plywood and solid timber poles; they are protected with a durable child/toy-safe finish.

*To clean, wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish. Do not use abrasive cleansers.

* Do not modify the unit. Rainbow Box is not responsible for any injury arising as a result of modifications made by customers to our products without our supervision, testing, or evaluation.

IMPORTANT - Retain these instructions for future reference.


Registered design.

Model - BP65 Batch Number: _____

Design and Manufactured by Rainbow Box UK,
2 - CF31 5FE www.rainbowbox.uk info@rainbowbox.uk



Tri Climb - BP645 - Folding



OPENING AND CLOSING

Your Tri Climb includes two thumb screws that are designed to lock the product in an open or closed position.

To open the Tri Climb:

- 1) Fully unscrew and remove both thumb screws from the sides of the unit
- 2) Holding the unit at the bottom edges, carefully open the unit. The mechanism may be stiff, which is by design to prevent accidental opening / closing
- 3) Once fully open, replace both thumb screws into the unit prior to use.

Closing the unit is the reverse of opening.

WARNING: Opening and closing should be attempted by adults only. The thumb screws are an important safety feature and should always be fully inserted prior to use or storage.

Suitable for ages 9months – 5years

Weight limit – 50kg





WARNINGS

*It is extremely important that you read and retain the information in this **WARNINGS** section to reduce the risk of injury.

*Warning contains small parts – choking hazard.

*Children must be supervised at all times while using the Tri Climb.

*No running, pushing or fighting.

*Only use the Tri Climb for its intended purpose. **For indoor use only**, in a domestic setting.

*Tip over hazard - Place play-frame on a level surface.

*Do not allow children to play on the Tri Climb frame until the unit is fully opened.

*Keep floors free of trip hazards and observe an obstacle free safety zone of approx. 2m in all directions around the unit.

*To minimise risk of injury from falling, do not install over a hard surface; a protective surface should be used. Maximum vertical fall height - 590mm

*Never allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this play-frame or to attach these items to the play-frame.

*Never allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using this Tri Climb

*Do not allow children to wear open toe or heel footwear like sandals or flip-flops whilst climbing.

*Do not permit rough play or use of equipment in a manner for which it was not intended. Jumping from the top, elevated rungs could be dangerous.

*Observe capacity limitations of your play-frame - 1 user maximum.

*Recommended age: 9 months – 5 years

*Weight limit – 50kg

*Not suitable for children under 36 months until fully assembled – fall hazard and small parts – choking hazard.

*Risk of entrapment when folding. Never allow children to open and close the frame – ensure the thumb screws are secure both in the open position and the folded position. **WARNING** – periodically check thumb screws to make sure they are securely in place.

Encourage – Enhance – Engage

Created to encourage children to be active, imaginative and creative in their play, the Tri Climb seeks to enhance balance, develop motor skills and engage both mind and muscle.

The Tri Climb is a perfect play frame for hours of energy-burning fun for the young climber. This robust frame is ideal for agile and active indoor play. It has a great natural look, which will blend into any living setting. Designed and built to the highest safety standards using FSC certified timber, the frame is extremely strong and sturdy. The frame is CE rated and has been put through rigorous, independent European safety tests (EN71) giving parents peace of mind while their children play.

Benefits of Play - The Tri Climb provides a surface designed for climbing which is intended for young children. Younger children are still developing a sense of judgement and learning the strength of their own bodies. They will be testing how far and how high they can jump and move. Their balance is still under development, and they are learning how to solve physical problems using their bodies. The Tri Climb therefore provides a chance to develop all sorts of skills appropriate to their age; climbing gives them the opportunity to test, retest and perfect their strength, coordination, self-confidence, concentration and independence.

The TRI Climb is hand crafted in South Wales by Rainbow Box UK, manufactured from E1 low emission compliant plywood and solid wood from sustainable sources (FSC). Our stains and lacquers use the latest developments in waterborne polymer technology and are safe, light-fast, tough, durable, nontoxic, environmental and child friendly - BS 5665-EN 71/3 Toy Safety Regulations 1995 certified. Products are hand finished with eco-friendly water-bourne lacquer, which gives a 'just visible grain' look and feel to the finish.

Dimensions: Open: L550 x W800 x H645mm
 Folded: L550 x W100 x H760mm